

取扱説明書

ミストフィルタエレメント マイクロミストフィルタエレメント

エレメントの交換手順


現在ご使用になられているエレメントの種類により交換方法が異なります。

- (1). フィルタエレメントセット FE300DK (0.3 μ m 用)、FE300MK (0.01 μ m 用) が装着されている場合。

(フィルタエレメント底部に十字穴付きナベ小ネジがついています。)



- ①. フィルタエレメントセットの十字穴付ナベ小ネジを使用し、フィルタエレメントセットを取り外す。(ネジガイドが本体に残った場合はそのままで結構です。③に進んでください。)
- ②. 十字穴付ナベ小ネジをネジガイドから外す。
- ③. エレメントの取外し
- ④. フィルタエレメントセット取り外し時にネジガイドも外れた場合は、ここで本体にネジガイドをねじ込み取り付ける。
- ⑤. ネジガイドに新しいフィルタエレメントをはめ込む。
- ⑥. 十字穴付ナベ小ネジにガスケット、キャップガイド、リンクの順で部品を挿入する。この時キャップガイドは突起の無い方をガスケット側にする。
- ⑦. フィルタエレメントを取り付けたネジガイドに⑥の部品を十字穴付ナベ小ネジを使用して締め付ける。この時の締め付けトルクは 0.9 ~ 1.1 N · m で締め付けてください。



- (2). フィルタエレメント FE300D (0.3 μ m 用)、FE300M (0.01 μ m 用) が装着されている場合。
(フィルタエレメント底部に十字穴付きナベ小ネジが付いていません。)

- ①. 1 回目の交換時は本体からフィルタエレメント FE300D または FE300M を取り外しフィルタエレメントセット FE300DK または FE300MK に交換してください。
- ②. 2 回目以降は (1). フィルタエレメントセット FE300DK、FE300MK の交換手順に従って交換してください。エレメントのみ (FE300DN、FE300MN) の交換となります。

※. その他詳細につきましてはカタログ、又は最寄りの営業所にお問い合わせください。

販売元／株式会社 **ピスコ** 販売

本社・営業部／長野県上伊那郡南箕輪村 3884-1 〒399-4586 TEL : 0265(76)2511(代) FAX : 0265(76)2851

製造元／株式会社 **日本ピスコ**

Handling Instruction

Mist Filter Element Micromist Filter Element

Replacing Method of Filter element


The method differs in the element types.

- (1). In case of the filter element set FE300DK (for $0.3\mu\text{m}$) and FE300MK (for $0.01\mu\text{m}$) are equipped.

(A cross-recessed round head screw is attached to the bottom of filter element.)



- ①. Using the cross-recessed round head screw, remove filter element set. (If screw guide remains inside of the main body, please leave it as it is and proceed to ③.)
- ②. Remove the cross-recessed round head screw from the screw guide.
- ③. Remove the element.
- ④. In case the screw guide comes off at the same time the filter element set is removed, screw it into the main body.
- ⑤. Install a new filter element into the screw guide.
- ⑥. Insert the parts into the cross-recessed round head screw in the order of gasket, cap guide and link. Do not place the gasket next to the protruding side of the cap guide.
- ⑦. Tighten the ⑥ parts by the cross-recessed round head screw to the screw guide with filter element. Please apply tightening torque of $0.9 \sim 1.1 \text{ N} \cdot \text{m}$.



- (2). In case of filter element FE300D (For $0.3\mu\text{m}$) and FE300M ($0.01\mu\text{m}$) are equipped.

(A cross-recessed round screw is not attached to the bottom of filter element.)

- ①. On the first time of replacement, remove the filter FE300D or FE300M from the main body and install filter element set FE300DK or FE300MK.
- ②. From the second time of replacement, please follow the replacement procedure of (1) of FE300DK and FE300MK. Replace the element only. (FE300DN, FE300MN)

※ . Please contact your nearest PISCO office or refer to catalogue for other detail.

NIHON PISCO CO.,Ltd.

INTERNATIONAL MARKETING DEPT.

3884-1 MINAMIMINOWA, KAMIINA, NAGANO-PREF, 399-4588 JAPAN

TEL: +81-265-76-7751 FAX: +81-265-76-7789

URL: pisco.co.jp/english/pisco.htm E-mail: intl@pisco.co.jp